AUTODOC CLUB

How to change spark plugs on **Audi A4 B8** – replacement guide

VIDEO TUTORIAL



Important!


This replacement procedure can be used for:
AUDI TT Coupe (8J3) 2.0 TFSI, AUDI TT Coupe (8J3) 2.0 TFSI quattro, AUDI TT Roadster (8J9) 2.0 TFSI, AUDI TT Roadster (8J9) 2.0 TFSI quattro, AUDI A6 Saloon (4G2, 4GC, C7) 2.0 TFSI, AUDI Q5 (8RB) 2.0 TFSI hybrid quattro, AUDI A6 Avant (4G5, 4GD, C7) 2.0 TFSI, AUDI Q3 (8UB, 8UG) 2.0 TFSI quattro, AUDI A5 Convertible (8F7) 1.8 TFSI, AUDI A6 Saloon (4G2, 4GC, C7) 2.0 TFSI hybrid, AUDI A8 (4H2, 4H8, 4HC, 4HL) 2.0 TFSI hybrid, AUDI A3 Sportback (8PA) 2.0 TFSI, AUDI A3 Sportback (8PA) 2.0 TFSI quattro, AUDI A3 Hatchback (8P1) 2.0 TFSI, AUDI A3 Hatchback (8P1) 2.0 TFSI quattro, (+ 44)

The steps may slightly vary depending on the car design.





REPLACEMENT: SPARK PLUGS – AUDI A4 B8. TOOLS YOU MIGHT NEED:



- High-temperature anti-seize lubricant
- Torx bit T30
- Spark plug socket # 16
- Ratchet wrench
- Torque wrench
- Telescoping magnet
- Fender cover


BUY TOOLS

Replacement: spark plugs – Audi A4 B8. AUTODOC experts recommend:


- The replacement procedure is the same for all spark plugs.
- Please note: all work on the car – Audi A4 B8 – should be done with the engine switched off.

REPLACEMENT: SPARK PLUGS – AUDI A4 B8. TAKE THE FOLLOWING STEPS:

1 Open the hood.



2 Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.



3 Remove the engine cover.







Replacement: spark plugs – Audi A4 B8. Tip:

- Raise the engine cover, holding it on two sides simultaneously.
- Do not apply excessive force when removing the part. Otherwise you may damage it.

4 Unscrew the fasteners of the ignition coil harness retainer. Use Torx T30. Use a ratchet wrench.



5 Unplug the connectors from the ignition coils.



6 Take out the ignition coils from the spark plug wells.











Replacement: spark plugs – Audi A4 B8. AUTODOC recommends:

- Remember the sequence of steps for ignition coil demounting.


7 Clean dirt, dust and debris from inside the spark plug wells.



8 Unscrew the spark plugs. Use the spark plug socket #16. Use a ratchet wrench.



9 Take out the spark plugs. Use a telescoping magnet.



10 Apply a thin layer of a special high temperature anti-seize lubricant to the threads of the new spark plugs.











11 Install the new spark plugs into their mounting seats. Use the spark plug socket #16.




12 Screw new spark plugs and tighten them. Use the spark plug socket #16. Use a torque wrench. Tighten it to 27 nm torque.



Replacement: spark plugs – Audi A4 B8. AUTODOC experts recommend:

- Don't tighten the plugs with excessive force. Exceeding tightening torque can damage the thread connection.
- Be careful when working with a spark plug wrench. Its skewing can cause damage to the threaded connection.

13 Install the ignition coils to the spark plug wells. Make sure you hear a click indicating that it is locked in place.



AUTODOC recommends:

- Replacement: spark plugs – Audi A4 B8. Follow the installation steps.

14




Plug in the connectors of the ignition coils.




15

Screw in the fasteners of the ignition coil harness retainer. Use Torx T30. Use a ratchet wrench.



16

Install the engine cover and secure it.




Replacement: spark plugs – Audi A4 B8. Tip from AUTODOC experts:

- Make sure the engine cover is properly seated. It should not be displaced with respect to the guiding fasteners.
- Do not apply excessive force when installing the part. Otherwise you may damage the fasteners.

17 Remove the fender protection cover.



18 Close the hood.



19 Run the engine for a few minutes. This is necessary in order to make sure that the component operates properly.

20 Shut off the engine.




VIEW MORE TUTORIALS





AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR AUDI

SPARK PLUGS: A WIDE SELECTION





CHOOSE CAR PARTS FOR AUDI A4 B8

SPARK PLUGS FOR AUDI: BUY NOW

SPARK PLUGS FOR AUDI A4 B8: THE BEST DEALS & OFFERS

DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.